

# T-REX TRUCK PRODUCTS INC.

99101

(1670144P)

Street Scene #70144

2003 CHEVY

SILVERADO

SS BUMPER COVER

BILLET INSERT

99101

(1670144P)

Street Scene #70144

2003 CHEVY

SILVERADO

SS BUMPER COVER

BILLET INSERT

## STREET SCENE 2003 CHEVY SILVERADO SS

**Bumper Cover Billet (Street Scene #70144)**

### Tools Required:

Phillip Screw Driver

Drill

1/8" Drill Bit

### Hardware / Parts Included:

1 - Billet Bumper Insert (7 Bars)

2 - #8 x 3/4 Phillip Screws

2 - #8 Flat Nuts

## Read and understand instructions before attempting installation

### Step 1

Place the bumper billet in the bumper cover opening.

### Step 2

Mark the location of the two brackets on the billet insert. Drill a 1/8" hole at each mark. Fasten using the hardware provided.

### Step 3

Installation of the billet bumper insert is complete. *Thank you for purchasing your T-Rex billet grille.*