

STEP 1 Center billet grille in lower bumper opening. Place 1/4-20 x 1 1/2" SHCS thru both Billet Grille & Factory Grille. Then place the supplied tabs & nuts on backside of facory grille as shown above and tighten.

NOTE: Please adjust horizontal blades if irregular. This is the result of shipping and handling outside of Weston's control.

Also Weston recommends applying a high quality automotive wax to maintain the original appearance.