



INSTALLATION INSTRUCTIONS

APPLICATION: 1996-2000 FORD EXPLORER

**SPORTSMAN
TAILLIGHT
GUARD**
39-3085

CAUTION:
BEFORE BEGINNING
INSTALLATION
PROCEDURE,
READ THROUGH
INSTRUCTIONS
CAREFULLY AND
COMPLETELY

HARDWARE KIT: 8 ea. # 14 x $\frac{3}{4}$ " Hex washer head self tapping screws

STEP 1: There are left and right side TailLight Guards. They attach to inside of rear hatch jamb using self tapping hex screws provided in parts kit, while the outer portion of Guard rests against body panels with rubber bumper.

STEP 2: Position appropriate TailLight Guard in center of taillight lens with formed mounting bracket resting against inside rear hatch jamb. Mark location of existing holes in mounting bracket onto jamb. Center punch locations marked.

STEP 3: Drill where marked into jamb using $\frac{7}{64}$ " drill bit. Attach Guard where drilled using self tapping screws provided. Tighten completely, but use care to avoid stripping threads.

STEP 4: Repeat procedure on opposite side. Installation is complete.

