

Trailblazer Front Winch Mount Bumper

PART NUMBER	
42-2015	

REQUIRED TOOLS	
<ul style="list-style-type: none"> • Ratchet • Torque Wrench 	

PARTS	
QTY	PRODUCT
1	Front Bumper
8	12-1.75mm x 35mm Hex Head Bolts
8	12mm Lock Nuts
16	Flat Washers

WARRANTY	
3 YEARS	



FIGURE 1
 Installed Trailblazer Front Bumper



INSTRUCTIONS:

1. REMOVE CONTENTS FROM BOX. VERIFY ALL PARTS ARE PRESENT. READ INSTRUCTIONS CAREFULLY.
2. Remove the four bolts on the passenger side and the four bolts on the driver side securing factory bumper to the frame. Disconnect any wiring from the bumper and remove completely.
NOTE: Use a zip tie to secure wiring under the hood.
3. Position the Trailblazer Bumper onto vehicle and line up the holes on the bumper with holes on the frame.
4. Secure bumper to frame by using the included (8) 12-1.75mm Hex Head Bolts, (8) 12mm lock Nuts, and (16) 12mm Flat Washers (Figure 1). Do not fasten bolts at this time.
5. Level and adjust Front Bumper, then fasten all hardware at this time to 55 ft/lb.
6. Do periodic inspections to the installation to make sure that all hardware is secure and tight.

CARE INSTRUCTIONS

- BLACK FINISHES SHOULD BE CLEANED WITH MILD SOAP AND WATER