

## INSTRUCTIONS—INSTRUCCIONES—CONSIGNES

APPLICATION: 2005-2011 DODGE DAKOTA APP PART # 37-01660, 37-01665 OFF ROAD LIGHT BAR


ITEM	QUANTITY	DESCRIPTION	TOOLS NEEDED
1	1	OFF ROAD LIGHT BAR	16MM SOCKET
2,3	2	MOUNTING BRACKETS (2) DRIVERS SIDE, (3) PASSENGER SIDE	16MM WRENCH
4	4	M10 HEX HEAD BOLTS	RATCHET
5	8	M10 FLAT WASHERS	TORQUE WRENCH
6	4	M10 LOCK WASHERS	
7	4	M10 HEX NUTS	

## ANTI-SEIZE LUBRICANT MUST BE USED ON ALL STAINLESS STEEL FASTENERS TO PREVENT THREAD DAMAGE AND GALLING

- 1. Remove contents from box, verify if all parts listed are present and free from damage. Carefully read and understand all instructions before attempting installation.
- 2. Starting on the driver side remove the body mount bolt and inner-lower bumper mount nut (Fig.1). Do not discard. Note: Tow hooks must be removed to complete installation.
- 3. Install the driver side mounting bracket using factory hardware (Fig2). Do not fully tighten at this time.
- 4. Repeat steps 2 and 3 for the passenger side.
- 5. Attach the light bar to the inside of the mounting brackets using (4) M10 hex bolts, (8) M10 flat washers, (4) M10 lock washers and (4) M10 hex nuts (Fig 3).
- 6. Align and adjust the Light Bar as needed then fully tighten all hardware at this time. Torque all M10 hex bolts to 35-40 ft lbs

## CARE INSTRUCTIONS

- REGULAR WAXING IS RECOMMENDED. DO NOT USE ANY TYPE OF POLISH OR WAX THAT MAY CONTAIN ABRASIVES
- STAINLESS STEEL PRODUCTS CAN BE CLEANED WITH MILD SOAP AND WATER. STAINLESS STEEL POLISH SHOULD BE USED TO POLISH SMALL SCRATCHES.
- GLOSS BLACK FINISHES SHOULD BE CLEANED WITH MILD SOAP AND WATER













Westing Automotive Products, Inc. 5200 N. Irwindale Ave. Suite 220
• Irwindale, Ca. 91706