



INSTRUCTIONS—INSTRUCCIONES—CONSIGNES

APPLICATION: FORD F150 2006-2008
PART# 37-02015, 37-02010

| ITEM | QUANTITY | DESCRIPTION | TOOLS NEEDED |
|------|----------|-----------------------------|------------------------|
| 1 | 1 | LIGHT BAR ASSEMBLY | 18MM SOCKET AND RACHET |
| 2 | 2 | M12 DOUBLE NUT PLATE | 18MM WRENCH |
| 3 | 4 | M12 X 40MM HEX BOLT | TORQUE WRENCH |
| 4 | 4 | M12 FLAT WASHER | |
| 5 | 4 | M12 SPRING TYPE LOCK WASHER | |

1. Remove contents from box. Verify that all parts listed are present and free from damage. Read installation instructions carefully before attempting installation.
2. If the vehicle is equipped with front tow hooks, remove them by removing the 15MM bolts from below the vehicle frame. If the vehicle is a two wheel drive model. A pocket must be cut out of the lower plastic valance such as in a four wheel drive model.
3. Insert one M12 double nut plate into each of the front vehicle frame rail and align with the two holes at the bottom of the frame.
4. Attach the light bar assembly to the bottom of the frame rails using the M12 hex bolts, washers, and lock washers to secure to the nut plates already inserted.
5. If desired, the factory tow hooks can be installed below the light bar brackets in their original positions. It is recommended to use the factory fasteners to secure the tow hooks and light bar.
6. Align light bar as desired and tighten all fasteners. Tighten to 30-45 lbs/ft



Westin Automotive Products, Inc.
5200 N. Irwindale Ave. Ste 220
Irwindale, Ca 91706

Thank You for choosing Westin products
For additional installation assistance please call
Customer Service (800)793-7846