



Platinum Series Bug Shield
No Drill BUG DEFLECTOR

Installation Instruction: GG

***Before you begin installation please note you have two different sets of screws. Two of them are noticeably bigger. The bigger set installs in the two inside holes.

- 1) Thoroughly clean front hood area. Open hood.
- 2) "Dry Fit" the bugshield by holding it up to the hood. Note which holes in your bugshield line up with the plastic plugs on your vehicles weather stripping. (This will also help verify if you have the correct shield for your vehicle).
- 3) Remove **ONLY** the plastic plugs from the weather-stripping that corresponded with the holes in your bugshield (using a pair of pliers or a fork).

Using a screw driver, complete the following.

- 4) Place shield **UNDER** the weather-stripping and with the screw and grummetts Install the two center screws (using the two bigger screws) into the corresponding, pre-existing holes. Be sure to go through the shield, weather-stripping and into the hole.

DO NOT OVER TIGHTEN

- 5) Pull the outer tags toward the front of the vehicle until the contours of the shield match the contours of the hood. Install the remaining screws into the pre-existing holes.
- 6) Close hood and tell all your friends about your **FANTASTIC** new shield from **WADE**.

Cleaning Instructions: Wash with warm water and a mild soap solution using a soft, clean cloth or sponge. Use of cleaners not approved for acrylic, or use of improper solvents could result in permanent damage which will not be covered by the warranty.

Warning: All items are made of breakage resistant material, but to avoid damage, machine car washes are not advised.

2- 5/16 x 1/2 BAS screws, 2- 5/16 washers, 2- #14 X1/2 Panhead SMS, 2- Grommets



Platinum Series Bug Shield
No Drill BUG DEFLECTOR

Installation Instruction: GG

***Before you begin installation please note you have two different sets of screws. Two of them are noticeably bigger. The bigger set installs in the two inside holes.

- 1) Thoroughly clean front hood area. Open hood.
- 2) "Dry Fit" the bugshield by holding it up to the hood. Note which holes in your bugshield line up with the plastic plugs on your vehicles weather stripping. (This will also help verify if you have the correct shield for your vehicle).
- 3) Remove **ONLY** the plastic plugs from the weather-stripping that corresponded with the holes in your bugshield (using a pair of pliers or a fork).

Using a screw driver, complete the following.

- 4) Place shield **UNDER** the weather-stripping and with the screw and grummetts Install the two center screws (using the two bigger screws) into the corresponding, pre-existing holes. Be sure to go through the shield, weather-stripping and into the hole.

DO NOT OVER TIGHTEN

- 5) Pull the outer tags toward the front of the vehicle until the contours of the shield match the contours of the hood. Install the remaining screws into the pre-existing holes.
- 6) Close hood and tell all your friends about your **FANTASTIC** new shield from **WADE**.

Cleaning Instructions: Wash with warm water and a mild soap solution using a soft, clean cloth or sponge. Use of cleaners not approved for acrylic, or use of improper solvents could result in permanent damage which will not be covered by the warranty.

Warning: All items are made of breakage resistant material, but to avoid damage, machine car washes are not advised.

2- 5/16 x 1/2 BAS screws, 2- 5/16 washers, 2- #14 X1/2 Panhead SMS, 2- Grommets