




INSTALLATION INSTRUCTIONS

APPLICATION: 2002-05 DODGE RAM 1500;
2003-05 DODGE RAM 2500/3500

AUTOMOTIVE PRODUCTS, INC.



BILLET GRILLE		TOOLS REQUIRED
VERTICAL	34-5240	Phillips Screwdriver 7mm Wrench
QTY	HARDWARE CONTENTS	
4	BILLET GRILLE - 4 Inserts	
12	M4 x 25MM PHILLIPS SCREWS	
12	M4 FLANGE NUTS	
12	METAL BRACKETS - FLAT	

PRODUCT INSTALLATION:

- Verify all hardware contents listed above are present. Carefully read all Instructions before installing.
NOTE: Determine the correct placement of the 4 grille inserts before installing to avoid damage to the vehicle or product.
- Open hood to access the backside of OE Grille. Position the top-left panel (TL) over existing OE Grille (Honeycomb).
SEE FIGURE 1 From the front side of the Billet Grille, insert 3 M4 x 25mm screws through the existing holes on Billet Grille. Fasten all screws using the provided Metal Brackets and M4 Flange Nuts from back-side of OE Grille.
NOTE: Do not fully tighten screws at this time. **SEE FIGURE 2**
- Repeat step 2 on remaining inserts. Once the 4 grille inserts have been loosely attached, align the top and bottom inserts to desired position and tighten all fasteners evenly. **NOTE: DO NOT OVERTIGHTEN HARDWARE.**

FIGURE 1 - Correct Placement of Grille Inserts



FIGURE 2 - Metal Bracket / M4 Flange Nut

