



### In-Channel Wind Deflector Installation Instruction: # 2

Front Doors only

- 1) Roll down the front windows all the way.
- 2) "Dry Fit" the wind deflector by holding it up to the window.

**IMPORTANT:** The stem on the bottom edge of the part **MUST** rest in the groove of the outer door weather-strip.

3) The deflector must be fitted into the same channel as the door window glass. With the alcohol pad provided clean the inside of the window channel where the transfer tape, and the red backed tape will adhere (wait a moment for the alcohol to evaporate). Then, making sure to avoid contact with your skin, apply the "3M" Adhesion Promoter to the inside of the window channel and where the red backed "3M" tape will adhere.

4) Remove masking from the transfer tape and **START** to remove the red backing from tape by loosening it.

5) Starting at the bottom corner, insert deflector into channel nearest to the mirror. Slowly work your way upward until the deflector is all the way in the window channeling. Then fully remove the red backing from the remaining tape.

6) Roll your window up and down at **LEAST** five time. **IT IS IMPORTANT** that you gently force your window up these **FIVE** times, so as not put a strain on your window motor.

7) You must leave your window closed for at least 72 hours after installation. This will ensure that your new deflector both "finds a home" by having the rubber form around it, and giving the tape time to cure. **IMPORTANT:** The stem on the bottom edge of the part **MUST** rest in the groove of the outer door weather-strip.

Rear Doors (if applicable)

- 1) Follow above steps 1-4
- 2) Place deflector at an angle in which you can insert both sides into channeling
- 3) With an upward motion place deflector fully into window. **HOLDING IT IN PLACE** finish steps 6-7 (above).

**Cleaning Instructions:** Wash with warm water and a mild soap solution using a soft, clean cloth or sponge. Use of cleaners not approved for acrylic, or use of improper solvents could result in permanent damage which will not be covered by the warranty.

**Warning:** All items are made of breakage resistant material, but to avoid damage, machine car washes are not advised.



### In-Channel Wind Deflector Installation Instruction: # 2

Front Doors only

- 1) Roll down the front windows all the way.
- 2) "Dry Fit" the wind deflector by holding it up to the window.

**IMPORTANT:** The stem on the bottom edge of the part **MUST** rest in the groove of the outer door weather-strip.

3) The deflector must be fitted into the same channel as the door window glass. With the alcohol pad provided clean the inside of the window channel where the transfer tape, and the red backed tape will adhere (wait a moment for the alcohol to evaporate). Then, making sure to avoid contact with your skin, apply the "3M" Adhesion Promoter to the inside of the window channel and where the red backed "3M" tape will adhere.

4) Remove masking from the transfer tape and **START** to remove the red backing from tape by loosening it.

5) Starting at the bottom corner, insert deflector into channel nearest to the mirror. Slowly work your way upward until the deflector is all the way in the window channeling. Then fully remove the red backing from the remaining tape.

6) Roll your window up and down at **LEAST** five time. **IT IS IMPORTANT** that you gently force your window up these **FIVE** times, so as not put a strain on your window motor.

7) You must leave your window closed for at least 72 hours after installation. This will ensure that your new deflector both "finds a home" by having the rubber form around it, and giving the tape time to cure. **IMPORTANT:** The stem on the bottom edge of the part **MUST** rest in the groove of the outer door weather-strip.

Rear Doors (if applicable)

- 1) Follow above steps 1-4
- 2) Place deflector at an angle in which you can insert both sides into channeling
- 3) With an upward motion place deflector fully into window. **HOLDING IT IN PLACE** finish steps 6-7 (above).

**Cleaning Instructions:** Wash with warm water and a mild soap solution using a soft, clean cloth or sponge. Use of cleaners not approved for acrylic, or use of improper solvents could result in permanent damage which will not be covered by the warranty.

**Warning:** All items are made of breakage resistant material, but to avoid damage, machine car washes are not advised.