



## Platinum Series Bug Shield BUG DEFLECTOR

Installation Instruction: CC

---

- 1) Thoroughly clean front hood area. Open hood.
- 2) "Dry Fit" the bugshield by holding it up to the hood. Note which holes in your vehicle line up with the holes in your bugshield.  
(This will also help verify if you have the correct shield for your vehicle).
- 3) Remove the two rubber bumpers near the center of the hood.
- 4) Insert the two plastic push pins into holes of the bumpers you just removed.  
**BUT DO NOT PUSH THE PINS IN ALL THE WAY.**
- 5) Mark the position of the two outside holes. Remove shield.
- 6) **CAREFULLY** drill the marked holes with a 1/8" drill bit
- 7) Replace the shield back in place and install the two center "plugs". Lock them in place.
- 8) Now complete the installation by screwing in the two remaining screws and grommit.  
**DO NOT OVER TIGHTEN SCREWS OR YOU WILL VOID THE WARRANTY.**
- 9) Before closing the hood make certain the shield is properly centered by "eyeballing" the two ends (you may need to loosen the screws and move the shield to either the left or right).
- 10) Close hood and tell all your friends about your **FANTASTIC** new shield from **WADE**.

Cleaning Instructions: Wash with warm water and a mild soap solution using a soft, clean cloth or sponge. Use of cleaners not approved for acrylic, or use of improper solvents could result in permanent damage which will not be covered by the warranty.

Warning: All items are made of breakage resistant material, but to avoid damage, machine car washes are not advised  
2- # 10 X 1/2 Phillip Truss, 2- Black Grommits, 2- Large Split Pushpin # 14010