



Platinum Series Bug Shield

No Drill BUG DEFLECTOR

Installation Instruction: DD

- 1) Thoroughly clean front hood area. Open hood.
- 2) "Dry Fit" the bugshield by holding it up to the hood. Note which holes in your bugshield line up with the plastic plugs on your vehicles weather stripping.
(This will also help verify if you have the correct shield for your vehicle).
- 3) Remove **ONLY** the plastic plugs from the weather-stripping that corresponded with the holes in your bugshield (using a pair of pliers or a fork).
- 4) Place shield **UNDER** the weather-stripping and insert the large screw. Be sure to go through the weather-stripping, shield and into the hole.

DO NOT OVER TIGHTEN SCREW OF YOU WILL VOID THE WARRANTY

- 5) Before closing the hood make certain the shield is properly centered by "eyeballing" the two ends (you may need to loosen the screws and move the shield to either the left or right).
- 6) Close hood and tell all your friends about your **FANTASTIC** new shield from **WADE**.

Cleaning Instructions: Wash with warm water and a mild soap solution using a soft, clean cloth or sponge. Use of cleaners not approved for acrylic, or use of improper solvents could result in permanent damage which will not be covered by the warranty.

Warning: All items are made of breakage resistant material, but to avoid damage, machine car washes are not advised.

4- 5/16 washer, 4- 5/16 x 1/2 BAS screws

www.wadeauto.com
www.westinautomotive.com