



## Platinum Series Bug Shield

No Drill BUG DEFLECTOR

Installation Instruction: EE

---

- 1) Thoroughly clean front hood area. Open hood.
- 2) "Dry Fit" the bugshield by holding it up to the hood. Note which holes in your bugshield line up with the pre-existing holes in your hood. (This will also help verify if you have the correct shield for your vehicle).
- 3) Insert nylon pushpins into the pre-existing holes.

Before locking push pin in place by pushing in the nylon plugs make certain the shield is properly centered by "eyeballing" the two ends (you may need to move the shield to either the left or right).

- 4) Push in Locking Pin.

**Install Tip:** It is possible to push the pin in with only the use of your hand. But, if you are unable to do this, due to the tight fit of the locking pin, we would suggest **LIGHTLY** tapping it in with the use of a hammer.

- 5) Close hood and tell all your friends about your **FANTASTIC** new shield from **WADE**.

Cleaning Instructions: Wash with warm water and a mild soap solution using a soft, clean cloth or sponge. Use of cleaners not approved for acrylic, or use of improper solvents could result in permanent damage which will not be covered by the warranty.

Warning: All items are made of breakage resistant material, but to avoid damage, machine car washes are not advised.