



## Platinum Series Bug Shield

### No Drill BUG DEFLECTOR

Installation Instruction: F

---

- 1) Thoroughly clean front hood area. Open hood.
- 2) "Dry Fit" the bugshield by holding it up to the hood. Note which holes in your bugshield line up with the existing holes in your hood.  
(This will also help verify if you have the correct shield for your vehicle).
- 3) You may need to remove the two rubber bumpers near the center of the hood (not all vehicles have the rubber bumpers mentioned).
- 4) You should have two separate sets of hardware. Comprising of two push pins and two screws. Install the larger set of push pins into the two center holes. Now install the screws into the two outside holes.  
**DO NOT OVER TIGHTEN.**
- 5) Slowly close the hood and check for sufficient clearance between the bugshield and the grill. **DO NOT HOLD BUGSHIELD WHILE CLOSING OR OPENING HOOD.**
- 6) Before closing the hood make certain the shield is properly centered by "eyeballing" the two ends (you may need to loosen the screws and move the shield to either the left or right).
- 7) Close hood and tell all your friends about your FANTASTIC new shield from WADE.

**Cleaning Instructions:**

Wash with warm water and a mild soap solution using a soft, clean cloth or sponge. Use of cleaners not approved for acrylic, or use of improper solvents could result in permanent damage which will not be covered by the warranty

**Warning:** All items are made of breakage resistant material, but to avoid damage, machine car washes are not advised