



# Platinum Series Bug Shield

## No Drill BUG DEFLECTOR

Installation Instruction: H

---

- 1) Thoroughly clean front hood area.
- 2) Open Hood.
- 3) Loosen the bolts which hold the grill to the hood (on some vehicles they may need to be removed).
- 4) Pull the grill forward and slide the bugshield between the grill and the hood.
- 5) Position the bugshield in the center of the hood and reinstall, or re-tighten the bolts. **DO NOT OVER TIGHTEN BOLTS.**
- 6) Close hood and tell all your friends about your **FANTASTIC** new shield from WADE.

**Cleaning Instructions:**

Wash with warm water and a mild soap solution using a soft, clean cloth or sponge. Use of cleaners not approved for acrylic, or use of improper solvents could result in permanent damage which will not be covered by the warranty.

**Warning:** All items are made of breakage resistant material, but to avoid damage, machine car washes are not advised