



Platinum Series Bug Shield

Installation Instruction: I

It is VITAL that you read and follow these instructions BEFORE you begin installation. Failure to do so can result in damage to your hood which will NOT be covered by the warranty.

- 1) Thoroughly clean front hood area. Open hood.
- 2) "Dry Fit" the bugshield by holding it up to the hood. Note which holes in your vehicle line up with the holes in your bugshield.
(This will also help verify if you have the correct shield for your vehicle).
- 3) Place the nylon insert squares (plugs) into the corresponding (center) holes.
(Note: Steps 3-4 ONLY apply to the center holes)
- 4) Place washer onto screw and apply slight pressure to the shield while screwing in (this will keep the other plugs from working themselves out).

DO NOT OVER TIGHTEN SCREW OR YOU WILL VOID THE WARRANTY.

- 5) MAKE SURE THE OUTSIDE HOLES LINE UP DIRECTLY OVER THE TWO SMALL PROTRUSIONS (ON THE UNDERSIDE OF YOUR HOOD). IF THEY DO NOT, UN-INSTALL SHIELD AND CALL YOUR WADE REPRESENTATIVE. HOOD DAMAGE WILL OCCUR IF PROTRUSIONS ARE NOT PRESENT.
- 6) Mark the position of where the holes should be and, with a 1/8" drill bit, carefully drill the two outside holes. IMPORTANT: Take care not to drill through or damage the top of the hood.
- 7) Screw in (by hand) the two screws with supplied washers .
- 8) Close hood and tell all your friends about your FANTASTIC new shield from WADE.

Cleaning Instructions: Wash with warm water and a mild soap solution using a soft, clean cloth or sponge. Use of cleaners not approved for acrylic, or use of improper solvents could result in permanent damage which will not be covered by the warranty.

Warning: All items are made of breakage resistant material, but to avoid damage, machine car washes are not advised