



*Platinum Series* Bug Shield  
No Drill BUG DEFLECTOR

Installation Instruction: N

---

- 1) Thoroughly clean front hood area. Open hood.
- 2) "Dry Fit" the bugshield by holding it up to the hood. Note which holes in your bugshield line up with the **two outside** plastic plugs on your vehicles weather stripping.  
(This will also help verify if you have the correct shield for your vehicle).
- 3) Remove **ONLY** the plastic plugs from the weather-stripping that corresponded with the holes in your bugshield (using a pair of pliers or a fork).
- 4) Place shield **UNDER** the weather-stripping and with the screw and grumets. Install shield. Be sure to go through the shield, weather-stripping and into the hole.

**DO NOT OVER TIGHTEN**

- 5) Push in the two center "christmas tree" plugs into the two center holes.
- 6) Close hood and tell all your friends about your **FANTASTIC** new shield from **WADE**.

Cleaning Instructions: Wash with warm water and a mild soap solution using a soft, clean cloth or sponge. Use of cleaners not approved for acrylic, or use of improper solvents could result in permanent damage which will not be covered by the warranty

Warning: All items are made of breakage resistant material, but to avoid damage, machine car washes are not advised

2- #14 x 1/2 phillips truss, 2 - grommets, 2-"christmas tree push pins

[www.wadeauto.com](http://www.wadeauto.com)  
[www.westinautomotive.com](http://www.westinautomotive.com)