



Platinum Series Bug Shield

Installation Instruction: W

Before you begin installation please note you have two different sets of screws. Two of them are noticeably bigger. The bigger set installs in the two **inside** holes.

- 1) Thoroughly clean front hood area. Open hood.
- 2) "Dry Fit" the bugshield by holding it up to the hood.
(This will help verify if you have the correct shield for your vehicle).
- 3) Install the two center screws (using the two bigger screws) into the corresponding, pre-existing holes. **DO NOT OVER TIGHTEN.**
- 4) Hold bugshield securely in place and lower hood to determine that the shield is centered. Do so by "eyeballing" either end. Make adjustments as needed.
- 5) **VERY IMPORTANT:** Pull the outer tags toward the front of the vehicle until the contours of the shield match the contours of the hood.
- 6) Mark the position of the two outside holes.
- 7) Carefully drill the marked holes with a 1/8" drill bit.
IMPORTANT: Take care not to drill through or damage the top of hood.
- 8) Using a screw driver install the last two screws.
- 9) Close hood and tell all your friends about your **FANTASTIC** new shield from **WADE**.

Cleaning Instructions: Wash with warm water and a mild soap solution using a soft, clean cloth or sponge. Use of cleaners not approved for acrylic, or use of improper solvents could result in permanent damage which will not be covered by the warranty

Warning: All items are made of breakage resistant material, but to avoid damage, machine car washes are not advised

2- #10 X 1/2 Phillip Truss, 2- 14 X 1/2 Phillip Truss, 4- Grommets

www.wadeauto.com
www.westinautomotive.com