



Bugshield: Nissan Frontier '98 – 00
Nissan Xterra '98 - 01
Air and bug deflector

Installation Instructions

- 1- Clean front of hood area before installing bugshield.
- 2- Place bugshield in position, ensuring it fits tight against the hood.
- 3- Install using the "Christmas tree" plugs provided.
 - a. Lock in place by firmly pressing into hood.
- 4- Do not attach the clear rubber bump-ons to the shield or the warranty will be voided. It is essential for the clear rubber bump-ons to be attached to the vehicle hood or damage will occur. Use the alcohol prep pads to clean the area, where the shield touches the vehicle, large enough to affix the rubber bump-ons. Gently hold the shield away from the hood and place the bump-ons on the vehicle, between the shield and hood. Make certain that the bump-ons are positioned to keep the shield from contacting hood.

Cleaning instructions:

Wash with warm water and a mild soap solution using a soft cloth or sponge. Use of cleaners not approved for acrylic or use of improper solvents could result in permanent damage which will not be covered by the warranty.

WARNING: This bugshield is made of a breakage resistant material, but the avoid damage machine car washes are not advised.

4 – "Christmas tree" plugs