



Door Sill Protectors

Installation Instructions

PLEASE READ THESE INSTRUCTIONS BEFORE INSTALLATION

It is important to read the instructions fully before fitting. The double-sided tape adheres and cures best at temperatures above 65 degrees (F). If the Door Sill Protector is being fitted below 65 degrees, it is advisable to warm the contact area of the vehicle (a hot air gun or hair dryer may be used.)

- 1) Trial fit the Door Sill Protectors without removing the masking from the double-sided tape. Take note of the contact area.
- 2) With the alcohol pad provided, thoroughly clean the door where the tape will adhere. After cleaning, wipe dry with a clean, dry cloth. (NOTE: the area where the tape adheres must be clean and dry, and should not be touched after cleaning.)
- 3) Remove the masking from the double-sided tape.
- 4) Carefully position the Door Sill Protectors so it is centered along the horizontal surface (so it is not on the "upward curve" of the door frame. Once in place, rub over the taped edge firmly with a soft cloth to fully adhere the tape.
- 5) Repeat steps for opposite side (and for rear pieces if applicable.)

www.wadeauto.com
www.westinautomotive.com



Door Sill Protectors

Installation Instructions

PLEASE READ THESE INSTRUCTIONS BEFORE INSTALLATION

It is important to read the instructions fully before fitting. The double-sided tape adheres and cures best at temperatures above 65 degrees (F). If the Door Sill Protector is being fitted below 65 degrees, it is advisable to warm the contact area of the vehicle (a hot air gun or hair dryer may be used.)

- 1) Trial fit the Door Sill Protectors without removing the masking from the double-sided tape. Take note of the contact area.
- 2) With the alcohol pad provided, thoroughly clean the door where the tape will adhere. After cleaning, wipe dry with a clean, dry cloth. (NOTE: the area where the tape adheres must be clean and dry, and should not be touched after cleaning.)
- 3) Remove the masking from the double-sided tape.
- 4) Carefully position the Door Sill Protectors so it is centered along the horizontal surface (so it is not on the "upward curve" of the door frame. Once in place, rub over the taped edge firmly with a soft cloth to fully adhere the tape.
- 5) Repeat steps for opposite side (and for rear pieces if applicable.)

www.wadeauto.com
www.westinautomotive.com