



Takeda Engine Cover

PN: TC-5201B (Black)

Important!

Please read all instruction steps before you begin installation.

| Make | Model | Year | Engine |
|-------|-------|-----------|---------|
| Dodge | Dart | 2013-2016 | L4-2.0L |

Step 1. Remove the four grommets from the stock engine cover. Install them onto Takeda engine cover.

Step 2. Install the Takeda cover by pushing the grommets onto the stock mounting locations.

Your install is now complete!



Step 1



Step 2

advanced FLOW engineering

252 Granite Street, Corona, CA 92879

Support: 951-493-7100

www.aFePower.com