

5150 Eucalyptus Avenue Unit A Chino, Ca. 91710 888.360.3696

Description: Headlight Part Number: 111165 111166 111197 111198



Read complete instructions before installation! Improper installation may void warranty



Tools needed: Phillips screwdriver 10mm socket.



Step 2: Remove the two 10mm bolts holding in the headlight.



Step 5: Twist off the corner light bulb



Step 9: Remove the corner light bulb.





Step 3: Remove the 10mm located under the corner bulb on the headlight.



Step 7: Twist off the headlight bulb.



Step 10: Pull out the new headlight from the box.



Step 1: Remove the two phillips screw holding in the rubber guard.



Step 4: Pull out the headlight from the vehicle.



Step 8: Remove the headlight bulb from the wire harness.



Step 11: Plug in the corner light bulb wire harness into the new headlight.



Step 12: Plug in the headlight wire harness into the new headlight.



Step 13: Test all functions for proper installation before driving.



AnzoUSA[™] products are covered, by a limited one (1) year warranty, to be free of manufacturer's defects. However, certain AnzoUSA[™] product categories have warranty policies which differ from this standard, please contact your representative for detailed category information. Damage due to improper installation or road hazards is not covered. Seller and manufacturers' only obligations shall be to replace the product proven to be defective. Neither seller nor manufacturer shall be liable for any injury, loss or damage, direct or consequential, arising out of the use of or the inability to use the product. Before using, user shall determine the suitability of the product for its intended use, and user assumes all risk and liability whatsoever in connection therewith.

 \odot 2008 AnzoUSA $^{\mbox{\tiny TM}}.$ All rights reserved.