



Installation Instructions

For Part Numbers:

300-117 720-440 Airaid Oiled Media Filter
302-117 722-440 SynthaMax Dry Media Filter - Black
303-117 723-440 SynthaMax Dry Media Filter - Blue

2000-03 Dodge Dakota/ Durango
4.7L V8



INTAKE SYSTEMS FOR VEHICLES LISTED ARE 50 STATE LEGAL. SEE AIRAID.COM FOR CARB STATUS ON EACH PART FOR A SPECIFIC VEHICLE.

Component Identification

| | | |
|----|-----------------------|---|
| 1. | Airaid Premium Filter | 1 |
| 2. | Cool Air Dam | 1 |
| 3. | Weather Strip 26" | 1 |
| 4. | Speed Clamp | 1 |
| 5. | Airaid Decal | 1 |

Full color instructions can be viewed on our web site at Airaid.com. If you need any assistance please call 1-800-858-3333 to speak with a representative in our Customer Service Center before returning the product.

I Disconnect the negative battery cable.

II Remove air cleaner lid.

- Loosen the intake tube clamp at the air box lid.
- Disconnect the crankcase breather tube at the air box lid.
- Unclip the air box lid and remove.

III Install Airaid C.A.D.(Cool Air Dam)

- Mount the Airaid CAD in place of the original air box lid. Snap in place.
- Connect the intake tube to the Airaid C.A.D., and tighten the clamp.
- Reconnect the crankcase breather tube to the nipple on the CAD tube and secure with the black speed clamp provided.
- Install the Airaid Filter and weatherstrip onto the CAD as shown.
- Apply the Airaid Foil Decal onto the Panel as shown.

IV Finishing up.

- Check over all work. **Reconnect the negative battery cable.**
- Check hood clearance before closing.

Provision for Some 2003 Models:

If your vehicle is equipped with a dipstick tube that interferes with the location of the Airaid Intake System, an adjustment to the dipstick tube must be made. Firmly grasp the dipstick tube about 6 inches below the top with your left hand and carefully bend the tube towards the engine with your right hand. This will allow for clearance of the Airaid Intake System. Please refer to the image.





Thank you for purchasing the Airaid Intake System. Contact Airaid @ (800) 498-6951 8:00 AM - 5:00 PM MST weekdays for questions regarding fit or instructions that are not clear to you. Your Airaid Intake System was carefully inspected and packaged. Check that no parts are missing, or were damaged during shipping. If any parts are missing, contact Airaid. The air filter element is protected from direct exposure to water and debris; care should be taken not to drive through deep water. WATER INGESTION IS THE DRIVERS RESPONSIBILITY! The air filter is reusable and should be cleaned periodically.

FILTER IDENTIFICATION

722-440 Airaid SynthaMax Dry Media - Black

720-440 Airaid Oiled Media

723-440 Airaid SynthaMax Dry Media - Blue

**For your Oiled media filter
we suggest using the
AIRAID Filter Tune-Up
Kit!**

SynthaMax[®]

Do Not Oil



**P/N 790-551 Aerosol Spray
P/N 790-550 Squeeze Spray**



Synthamax Air Filters do not require oil. Service air filter as needed by cleaning with common non-petroleum all-purpose household cleaner and water. Simple Green[®], Formula 409[®] or equivalent works great. Apply cleaner to outside of air filter and allow to soak. Then flush filter clean from the inside out with a garden hose and repeat steps if necessary. Do not apply high pressure water or air to clean filter. Allow filter to air dry and reinstall.

INTAKE SYSTEMS FOR VEHICLES LISTED ARE 50 STATE LEGAL. SEE AIRAID.COM FOR CARB STATUS ON EACH PART FOR A SPECIFIC VEHICLE.