



**BX2123 Installation Instructions
1993-96 Nissan Quest
1993-96 Mercury Villager**

These vehicles weigh over 3500 lbs and require a Class III (5000 lb) rated tow bar, hitch, and accessories. Utilization of Blue Ox baseplates with any tow bar not approved by Automatic Equipment Mfg. Company invalidates the limited warranty.

1. Read the General Instruction Sheet included with this baseplate.
2. The baseplate mounts to the front underside of the car using six bolts supplied with the kit.
3. Just behind the bumper on the outside of the frame are two tie down brackets used to secure the vehicle during shipping. Each bracket is mounted to the frame with three bolts. Remove both tie down brackets and set them and their bolts aside.
4. The side mounts of the baseplate mount where the tie down brackets were. Use the 10mm bolts, lock washers, and flat washers supplied to bolt the baseplate to the vehicle. Use Loctite on the bolts before starting them.
5. When all bolts are started, push the baseplate up as far as possible and tighten the bolts completely.
6. The dimensional variations between otherwise identical cars can be considerable. While the location and size of the holes in the baseplate were designed to allow for easy installation, it may be necessary to file a hole slightly to allow a bolt to clear.
7. Install the tow bar and safety cables according to the instructions included in their packages.
8. Do not substitute other devices if the tow bar pin and clip are lost.
9. DEALER OR INSTALLER: BE CERTAIN THE USER RECEIVES THE INSTRUCTION SHEET.

Tools Required

14mm Wrench

17mm Wrench

Loctite Blue

Automatic

Parts List

Ref. No.	Qty.	Part No.	Description
1	1	61-4782	Weldment, Baseplate, BX2123
2	6	201-0423	10mm-1.25 x 35mm Bolt, Grade 8.8
3	6	203-0104	10mm Lock Washer
4	6	203-0003	3/8" Flat Washer

