

**INSTALLATION INSTRUCTIONS For Part #'s:
 INSTRUCCIONES DE INSTALACION Pour Partie Nos.:
 INSTRUCTIONS D'INSTALLATION Para Parte Nos.:
 10000, 11000**

NOTE:

US BEFORE ATTACHING MIRROR, WE RECOMMEND THAT YOU CLEAN VEHICLE MIRROR. YOU MAY ALSO WISH TO APPLY A THIN COAT OF WAX.
 REMOVE CUSTOM TOWING MIRROR BEFORE ENTERING AUTOMATIC CARWASHES. USE EXTRA CAUTION WHEN APPROACHING TIGHT SPACES, SUCH AS ATM TERMINALS, AND OTHER DRIVE-THROUGH SERVICES.

NOTA:

E ANTES DE COLOCAR EL ESPEJO, RECOMENDAMOS QUE USTED LIMPIE EL RETROVISOR DEL VEHICULO. TAMBIEN PUEDE APLICAR UNA CAPA FINA DE LA CERA.
 quite por favor la costumbre remolcar los espejos antes de entrar lavacochess automáticos. Utilice la precaución extra al acercarse los espacios apretados, tal como terminales de ATM y otros servicios para automovilistas

REMARQUE:

F AVANT D'ATTACHER LE RETROVISEUR DE REMORQUAGE, NOUS VOUS RECOMMANDONS DE NETTOYER LE RETROVISEUR DU VEHICULE. IL SE PEUT QUE VOUS VOULIEZ AUSSI APPLIQUER UNE COUCHE LEGERE DE CIRE.
 S'IL VOUS PLAÎT ENLEVER COUTUME TRACTER LES MIROIRS AVANT D'ENTRER LA VOITURE AUTOMATIQUE SE LAVE. UTILISER LA PRÉCAUTION SUPPLÉMENTAIRE EN APPROCHANT DES ESPACES TENDUS, TELS QUE LES TERMINAUX DE GUICHET AUTOMATIQUE ET LES AUTRES SERVICES D'UNITÉ-PAR

