



Installation Instructions

12-974IC

1. Test fit the new cover to make sure you have a proper fit.
2. Using ammonia based cleaner such as Windex, clean the original cluster area and the underside of your new Coverlay®.
3. Apply a bead of silicone around the edges of the underside of your Coverlay® as shown in the picture below.



4. Use masking tape to hold your new cover in place for 6 to 8 hours.