



## Installation Instructions

### *18-726IC and 18-727IC*

1. If your vehicle has tilt steering, put the steering wheel in the lowest position.
2. (EMERGENCY BRAKE MUST BE ON)
3. Test fit the new cover to make sure you have a proper fit.
4. Using ammonia based cleaner such as Windex®, clean the original cluster area and the underside of your new Coverlay®.
5. Apply a bead of silicone around the edges of the underside of your Coverlay® as shown in the picture below.



6. Use masking tape to hold your new cover in place for 6 to 8 hours.