



12-35

DOOR PANEL INSTALLATION INSTRUCTIONS

IMPORTANT

- **READ ALL INSTRUCTIONS BEFORE ATTEMPTING TO INSTALL PANELS.**
- **MAKE SURE YOU HAVE THE CORRECT PANELS FOR YOUR AUTOMOBILE.**
- **COVERLAY® DOOR PANELS ARE NOT EXACT DUPLICATES OF FACTORY ORIGINALS.**
- **IF YOU PLAN ON COLORING YOUR COVERLAY DOOR PANELS, DO IT PRIOR TO INSTALL.**

1. Remove door handle and window crank hand from your truck.
2. Remove the two (2) screws in the armrest cup of your truck if you have them.
3. Loosen the two bolts connected to the cup holder bracket and push down tight. Secure.
4. Position your new Coverlay® door panels on your truck door. Make sure the panels line up with the original holes in the door's sheet metal.
5. Install one (1) sheet metal screw through the panel armrest in to the sheet metal bracket on your door. This replaces the one (1) screw you first removed from your old armrest.
6. Replace the door handle and window crank handle.

Installation assistance is available

Mon.-Fri. 8:00 am – 3:30 pm CST at 1-800-633-7090.