



12-45 SERIES

DOOR PANEL INSTALLATION INSTRUCTIONS

IMPORTANT

- READ ALL INSTRUCTIONS BEFORE ATTEMPTING TO INSTALL PANELS.
 - MAKE SURE YOU HAVE THE CORRECT PANELS FOR YOUR AUTOMOBILE.
 - COVERLAY® DOOR PANELS ARE NOT EXACT DUPLICATES OF FACTORY ORIGINALS.
1. Remove door handle and window crank handle from your truck. Remove the two screws in the arm rest cup of your truck.
 2. Pull off the door panel, saving rubber handle cover. Install handle cover in cutout of new panel. Make sure the metal piece that holds the arm rest is in place and secure to inner sheet metal of door. If you plan to reinstall your chrome piece, save it along with all of the factory hardware. Save factory door panel as a guide so you can check the holes that you need to drill in the new door panel.
 3. Chrome piece hole locations are marked by slight indentions visible on the backside of the panel. Drill holes with a ¼" drill bit. Reinstall factory chrome piece with original hardware.
 4. Position your new Coverlay® door panel on your truck door. Make sure the new panel lines up with the original holes in the door's sheet metal and press into place.
 5. When installing the screws for your arm rest, you may have to use an awl or ice pick to line up fold u-nut in bracket on the arm rest.
 6. Replace the window crank handle and door handle.

Installation assistance is available Mon.-Fri. 8:00 am – 3:30 pm CST at 1-800-633-7090.