



12-50 SERIES

DOOR PANEL INSTALLATION INSTRUCTIONS

IMPORTANT

- READ ALL INSTRUCTIONS BEFORE ATTEMPTING TO INSTALL PANELS.
 - MAKE SURE YOU HAVE THE CORRECT PANELS FOR YOUR AUTOMOBILE.
 - COVERLAY® DOOR PANELS ARE NOT EXACT DUPLICATES OF FACTORY ORIGINALS.
1. Remove door handle trim and window crank handle from your truck.
 2. Remove the three screws from the bottom of armrest.
 3. Pull off the door panel and discard.
 4. Position your new door panel on the truck door. Make sure the nine (9) predrilled holes of your Coverlay® panel line up with the original holes in the door's sheet metal. If they do not line up correctly, you may need to ream the holes out slightly.
 5. Install "Christmas Tree" fasteners (provided) through the lined up holes of the panel and the original holes in the door's sheet metal.
 6. Below the armrest, install the three (3) sheet metal screws (provided) through the door panel into the sheet metal or plastic bracket of your door. These replace the three (3) screws you first removed from your old armrest.
 7. Replace the door handle trim and window crank handle.

Installation assistance is available Mon.-Fri. 8:00 am – 3:30 pm CST at 1-800-633-7090.