



## 12-55 SERIES

### DOOR PANEL INSTALLATION INSTRUCTIONS

#### IMPORTANT

- READ ALL INSTRUCTIONS BEFORE ATTEMPTING TO INSTALL PANELS.
  - MAKE SURE YOU HAVE THE CORRECT PANELS FOR YOUR AUTOMOBILE.
  - COVERLAY® DOOR PANELS ARE NOT EXACT DUPLICATES OF FACTORY ORIGINALS.
1. Remove door handle trim and window crank handle from your truck.
  2. Remove the screws from the armrest.
  3. Pull off the door panel and discard.
  4. Position your new door panel on the truck door. Make sure the six (6) predrilled holes of your Coverlay® panel line up with the original holes in the door's sheet metal. If they do not line up correctly, you may need to ream the holes out slightly.
  5. Install "Christmas Tree" fasteners (provided) through the lined up holes of the panel and the original holes in the door's sheet metal.
  6. Install the #8 x 1 ¼" screw (provided) back into armrest hole.
  7. Replace the door handle trim and window crank handle.

**Installation assistance is available Mon.-Fri. 8:00 am – 3:30 pm CST at 1-800-633-7090.**