



Part# 12-92N

## DOOR PANEL INSTALLATION INSTRUCTIONS

### IMPORTANT

- READ ALL INSTRUCTIONS BEFORE ATTEMPTING TO INSTALL PANELS.
- MAKE SURE YOU HAVE THE CORRECT PANELS FOR YOUR AUTOMOBILE.
- KEEP ALL ORIGINAL HARDWARE UNTIL INSTALLATION IS COMPLETE.

### 1. Removal Of Old Panels:

- a. Remove cover of window crank and slide away.
- b. Remove screw in window crank using a t-20 screwdriver.
- c. Remove screws in upper triangle of door panel and by armrest using Phillips screwdriver.
- d. Remove door panel using a door removal tool or putty knife.
- e. Remove reflector from original panel.

### 2. Install reflector into Coverlay door panel.

### 3. Installation of New Panels:

- a. Fit over door handle area first.
- b. Line up panels with window crank and pop-lock
- c. Push panel in firmly.
- d. Insert #8 1 ¾ automotive screw through hole in upper triangle into door.
- e. Install **original** arm rest screw.
- f. Install window crank and t-20 screw.

Hardware Kit Provided:

(2) # 8 x 1 ¾ automotive screws

Tools Needed:

Putty knife or door removal kit

For installation assistance call 1-800-633-7090 M-F 8:00 am to 4:30 pm. CST



## Our Warranty

Coverlay Manufacturing, Inc. warrants all of its products to be free of defects in workmanship and material. It further warrants that when properly installed our products will not warp or crack for the life of the vehicle. Uninstalled products reported defective after 30 days of receipt will not be covered under warranty. Color is not covered under warranty and photos may be required to determine warranty issues. If a product failure occurs, we will only replace the defective product in the original color. Cost of shipping and handling of replacement parts is not covered on warranty claims made after 30 days of receipt.

Furthermore, it is our policy that returns must be requested within 30 days of purchase. If a **Retail Purchaser** of any Coverlay® product which is purchased directly from our manufacturing site is not totally satisfied with his or her purchase they may request to return it within **30 days** of delivery date with copy of receipt for a full product refund. If purchased indirectly through a supplier of our product, the supplier must be contacted for return authorization. **Dealers and Distributors** must also request return authorization within **30 days** of delivery and upon receipt of return, credit for product will be issued less applicable restock fees. All products must not have been installed or altered and received back in “re-stock” condition or no refund will be applied. Products returned under this policy must be shipped back in original unaltered packaging with freight prepaid by purchaser.

**Prior to return of any product purchased directly, you must contact us at 1-800-633-7090 for an authorization number and return instructions. Return product must be received within 30 days of return authorization. *You must contact your supplier for return instructions if purchased indirectly.***

### **COLOR MATCH IS NOT GUARANTEED OR COVERED UNDER WARRANTY**

We offer 15 generic colors as a no charge convenience. These will not be a perfect match but will normally be complimentary to the vehicle interior. If an exact match is desired then you may obtain color code matched plastic dye in an aerosol can from your local automotive paint store. Repaint to your satisfaction before installing in your vehicle.