

## DOOR PANEL INSERT INSTALLATION INSTRUCTIONS

### IMPORTANT

- READ ALL INSTRUCTIONS BEFORE ATTEMPTING TO INSTALL INSERTS.
- MAKE SURE YOU HAVE THE CORRECT INSERTS FOR YOUR AUTOMOBILE.

### 1. Preparing for Installation

- a. Using a utility knife or razor blade, slice one line in vinyl above and one line below arm rest.
- b. Slice an additional line in vinyl inside grab handle area.



1-a



1-b

### 2. Installation of New Inserts

- a. Test fit new insert.
- b. Place new insert into position making sure to push in from the side to close any gap under the pull handle. While holding in place, pre-drill the 6 holes into the door using a 1/8" drill bit.
- c. Install screws provided in hardware kit through pre-drilled holes using a phillips screwdriver. **DO NOT APPLY TOO MUCH PRESSURE AS THE SCREWS SHOULD ONLY BE SNUG.**



2-b



2-c

### Tools Needed:

Utility Knife or Razor Blade  
Drill with 1/8" Drill Bit  
Phillips Screwdriver

### Included - Hardware Kit:

(12) #8 x 5/8" Phillips Tapping Screws

**Installation assistance is available  
Mon.-Fri. 8:00 am – 3:30 pm CST  
at 1-800-633-7090.**