



18-10K

KICK PANEL INSTALLATION INSTRUCTIONS

IMPORTANT

- **READ ALL INSTRUCTIONS BEFORE ATTEMPTING TO INSTALL PANELS.**
- **MAKE SURE YOU HAVE THE CORRECT PANELS FOR YOUR AUTOMOBILE.**
- **COVERLAY® KICK PANELS ARE NOT EXACT DUPLICATES OF FACTORY ORIGINALS.**

****IF YOU ARE NOT REUSING YOUR CHROME TRIM STRIP YOU WILL SKIP STEP ONE (1).***

- 1. If reusing your chrome trim***; locate the 11 predrilled holes at the very top of the kick panel. You will have to use an awl to ream out the holes. Line up the sharps on the back side of your chrome strip with the holes on the kick panel and insert them through the holes. Turn the kick panel over and fold the sharps over so they will hold snugly to the kick panel.
- 2. When installing the Coverlay® kick panels**, make sure that the vent holes in the kick panel are positioned at the rear, bottom of the door. Line up the edge of the kick panel with the edge of the back of your door panel.
- 3. Insert the first screw in the upper left hand corner.** Insert your next screw in the upper right hand corner. Move to the bottom left hand and lower right hand corners as you did for the screws above. Insert all remaining screws. Due to some variance in door styles, it may be necessary to drill some of the holes yourself. If this is the case, be sure to use a 1/8" drill bit.

OPTIONAL: You may reuse your hardware and washers from your original kick panels.

PARTS LIST

16 8 x 3/4" Screws

Installation assistance is available Mon.-Fri. 8:00 am – 3:30 pm CST at 1-800-633-7090.