



ADDITIONAL 18-205 INSTALLATION INSTRUCTIONS

***IMPORTANT* PRIOR TO CHECKING THE FIT OF YOUR 18-205 DASH COVER:**

1. Use a flat blunt tool such as a putty knife to gently pry slightly open the top portion of the bezel to the left of the steering column. Repeat same step across the top of the bezel on the right side of the steering column. **DO NOT REMOVE BEZELS...ONLY LOOSEN THE TOP PART.**



1-a



1-b

2. Open the glove box door and then follow general instructions for setting your cover.
3. **After setting dash cover according to general directions**, close glove box door and snap bezels back into place right to left with cover tucked in. (VIDEO AVAILABLE AT www.coverlaymfg.com or YouTube)



ADDITIONAL 18-205 INSTALLATION INSTRUCTIONS

***IMPORTANT* PRIOR TO CHECKING THE FIT OF YOUR 18-205 DASH COVER:**

1. Use a flat blunt tool such as a putty knife to gently pry slightly open the top portion of the bezel to the left of the steering column. Repeat same step across the top of the bezel on the right side of the steering column. **DO NOT REMOVE BEZELS...ONLY LOOSEN THE TOP PART.**



1-a



1-b

2. Open the glove box door and then follow general instructions for setting your cover.
3. **After setting dash cover according to general directions**, close glove box door and snap bezels back into place right to left with cover tucked in. (VIDEO AVAILABLE AT www.coverlaymfg.com or YouTube)