



**27-35**

## **DOOR PANEL INSTALLATION INSTRUCTIONS**

### **IMPORTANT**

- **READ ALL INSTRUCTIONS BEFORE ATTEMPTING TO INSTALL PANELS.**
- **MAKE SURE YOU HAVE THE CORRECT PANELS FOR YOUR AUTOMOBILE.**
- **COVERLAY® DOOR PANELS ARE NOT EXACT DUPLICATES OF FACTORY ORIGINALS.**
- **IF YOU PLAN ON COLORING YOUR COVERLAY DOOR PANELS, DO IT PRIOR TO INSTALL.**

1. Remove old door panels:
  - a. Pop out the two window grommets on top of the door panel
  - b. Remove pull strap
  - c. Remove old door panel using a putty knife to lift along the edges
2. Position your Coverlay® door panel on your truck door. Make sure the new panel lines up with the original holes in the door's sheet metal and press into place.
3. Re-install pull strap and window holders.

**Installation assistance is available**

**Mon.-Fri. 8:00 am – 3:30 pm CST at 1-800-633-7090.**