



PADDED ARM REST PAINT AND INSTALLATION INSTRUCTIONS

IMPORTANT

- **READ ALL INSTRUCTIONS BEFORE ATTEMPTING TO PAINT AND INSTALL ARM REST(S)**
- **MAKE SURE YOU HAVE THE CORRECT ARM REST(S) FOR YOUR AUTOMOBILE**
- **MAKE SURE PAINT IS COMPLETELY DRY PRIOR TO INSTALLATION**

PAINTING YOUR ARM REST(S)

- You can purchase vinyl paint in the OEM color of your choice from an automotive paint store.
- The arm rest(s) can only be painted once.
- Before painting, wipe arm rest(s) with an alcohol swab or pad.
- Let dry and spray with a light coat of paint.
- Let paint dry completely prior to installation.

INSTALLING YOUR ARM REST(S)

1973-1980 Chevrolet/GMC Arm Rest(s)

- Remove old arm rest from door panel
- Replace with Coverlay® arm rest(s) using original screws

1981-1991 Chevrolet/GMC Arm Rest(s)

1980-1991 Ford Arm Rest(s)

- Remove door panel from door
- Remove old arm rest from door panel
- Place Coverlay® arm rest on door panel
- Secure ¼" nut on stud
- Reinstall door panel onto door
- Insert screw through base of arm rest and secure

ENJOY YOUR NEW COVERLAY® ARM REST(S)

For assistance contact us at 1-800-633-7090 M-F 8:00 am. – 3:00 pm. CST