



Part #17-94 F Driver, 17-96 Driver

DOOR PANEL INSERT INSTALLATION INSTRUCTIONS

IMPORTANT

- READ ALL INSTRUCTIONS BEFORE ATTEMPTING TO INSTALL INSERTS.
- MAKE SURE YOU HAVE THE CORRECT INSERTS FOR YOUR AUTOMOBILE.

1. Preparing for Installation

- a. Using a utility knife or razor blade, cut along seam to ensure fabric lays flat. Gluing down fabric is not necessary. Do not remove control panel.



1-a



2-a

2. Installation of New Inserts

- a. Test fit new insert.
- b. Place new insert into position making sure to push in from the side to close any gap under the pull handle. While holding in place, pre-drill the countersunk indentions into the door using a 1/8" drill bit.
- c. Install screws provided in hardware kit through pre-drilled holes using a Phillips screwdriver.
DO NOT APPLY TOO MUCH PRESSURE AS THE SCREWS SHOULD ONLY BE SNUG.



2-b



2-c

Tools Needed:

Utility Knife or Razor Blade
Drill with 1/8" Drill Bit
Phillips Screwdriver

Included - Hardware Kit:

#8 x 5/8" Phillips Tapping Screws Included

**Installation assistance is available
Mon.-Fri. 8:00 am – 3:30 pm CST
at 1-800-633-7090.**