

# 55317

DODGE DAKOTA  
DODGE PICKUP  
DODGE RAM FULLSIZE  
DODGE RAMCHARGER  
PLYMOUTH TRAILDUSTER

WIRING LOCATION GUIDE  
GUÍA DE UBICACIÓN DEL CABLEADO  
IDE D'EMPLACEMENT DES FILS



## MUST READ FIRST!

All steps must be followed to ensure correct function of the T-Connector. To verify proper installation once installed, test by connecting a test light or properly wired trailer.

## ¡DEBE LEERSE PRIMERO!

Debe seguirse todos los pasos para asegurar el correcto funcionamiento del Conector-T. Para verificar la correcta instalación, pruebe conectando una luz de prueba o un remolque debidamente cableado.

## À LIRE D'ABORD!

Pour assurer le bon fonctionnement du T-Connector, il faut suivre toutes les étapes. Pour vérifier que l'installation a été bien effectuée, branchez un feu de test ou une remorque correctement filée.

03/20/09



## English

1. Starting on the drivers side along the frame rail locate the vehicles taillight wiring harness there will be connectors matching those on the T-connector.**[A]**

2. Separate the vehicles connectors making sure not to damage the locking tabs.**[B]** Insert the the T-connector-T. Para verificar la correcta instalación, pruebe conectando una luz de prueba o un remolque debidamente cableado.**[C]**

3. Route the T-connector end with the green wire to the passenger side. Make sure to avoid areas that may cut or pinch the wire. Repeat step 2 on the passengers side using the green wire.

4. Route the 4-flat to the center of the vehicle and secure in a convenient out of the way location. Secure any loose wires with the cable ties provided.

## WARNING!

Verify miscellaneous items that may be hidden behind or under any surface before drilling to avoid damage and/or personal injury.