

**WIRING LOCATION GUIDE  
GUÍA DE UBICACIÓN DEL CABLEADO  
IDE D'EMPLACEMENT DES FILS**



**MUST READ FIRST!**

All steps must be followed to ensure correct function of the T-Connector. To verify proper installation once installed, test by connecting a test light or properly wired trailer.

**¡DEBE LEERSE PRIMERO!**

Debe seguirse todos los pasos para asegurar el correcto funcionamiento del Conector-T. Para verificar la correcta instalación, pruebe conectando una luz de prueba o un remolque debidamente cableado.

**À LIRE D'ABORD!**

Pour assurer le bon fonctionnement du T-Connector, il faut suivre toutes les étapes. Pour vérifier que l'installation a été bien effectuée, branchez un feu de test ou une remorque correctement filée.

10/14/09

## **English**

1. Open the trunk and remove the plastic fasteners that hold the felt trunk liner in place behind the taillights. Pull out the trunk liner and locate the vehicles taillight wiring harness. The harness will have connectors that are similar to those on the T-connector harness.

2. Starting on the passenger side separate the connectors being sure not to damage the locking tabs. Insert the T-connector end with the yellow wire in-between the separated connectors. Make sure the connectors are fully inserted with locking tabs in place.

3. Route the T-connector end with the green wire behind the trunk liner to the passenger side. Repeat step 2 on the passenger side using the green wire.

4. Route the 4-flat wire to the center of the vehicle and out the trunk when in use. When not in use roll up and store in an out of the way location in the trunk. Reassemble everything removed during install.

**WARNING!**

Verify miscellaneous items that may be hidden behind or under any surface before drilling to avoid damage and/or personal injury.