

INSTALLATION / SAFETY INSTRUCTIONS

Step 1

Locate the black electrical junction box under the dash, to the left of the steering column. Remove the box cover and locate the empty vehicle connection point (A,B).

Step 2

Insert the connector on the CURT brake control harness into the vehicle connection point. Make sure the connector is fully inserted with locking tabs in place (C).

Step 3

Insert the brake control harness's black connector into the brake control's quick plug connector (D). Secure the brake control harness with the provided cable ties, avoiding any pinch points.

Step 4

Complete the installation using the brake control instructions. Mount the unit as directed and perform test procedures as instructed in the brake control user manual.

