

# 55303 FORD BRONCO

## WIRING LOCATION GUIDE GUÍA DE UBICACIÓN DEL CABLEADO IDE D'EMPLACEMENT DES FILS



### MUST READ FIRST!

All steps must be followed to ensure correct function of the T-Connector. To verify proper installation once installed, test by connecting a test light or properly wired trailer.

### ¡DEBE LEERSE PRIMERO!

Debe seguirse todos los pasos para asegurar el correcto funcionamiento del Conector-T. Para verificar la correcta instalación, pruebe conectando una luz de prueba o un remolque debidamente cableado.

### À LIRE D'ABORD!

Pour assurer le bon fonctionnement du T-Connector, il faut suivre toutes les étapes. Pour vérifier que l'installation a été bien effectuée, branchez un feu de test ou une remorque correctement filée.

12/21/2010

## English

1. Locate the vehicle's taillight wiring harness, behind the rear bumper. The vehicle's harness connectors will be located along the inside of each frame rail and will have connectors similar to those on the T-Connector harness.

2. Separate the vehicle connectors, taking care not to damage the locking tabs. Insert the T-Connector harness between the separated vehicle harness connectors. Make sure the connectors are fully inserted with locking tabs in place.

### WARNING!

Verify miscellaneous items that may be hidden behind or under any surface before drilling to avoid damage and/or personal injury.

4. Locate a suitable grounding point near the connector such as an existing screw with nut in the vehicle's frame or drill a 3/32" hole and secure white ground wire using ring terminal and screw provided.

5. Route the 4-flat wire to the center of the vehicle. Secure any loose parts of the T-Connector with the cable ties provided.

