INSTALLATION INSTRUCTIONS

🛦 WARNING: DO NOT EXCEED PRODUCT RATING OR TOW VEHICLE LAMP LOAD RATING, WHICHEVER IS LOWER

APPLICATIONS

Make	Model
Jeep	TJ (Canada)
Jeep	Wrangler

WIRING LOCATION GUIDE

SUVS, MINI & FULL-SIZED VANS (S)

Representative vehicle shown below

- S5 Behind driver side rear bumper
- S7 Behind passenger side rear bumper

CUSTOM WIRING HARNESS





NOTICE 🕄 🗇

All steps must be followed to ensure the wiring harness will function properly. Once installed, test for proper function by using a test light or connecting a properly wired trailer.

TOOLS NEEDED

N/A

🔺 WARNING 🔺 🔺

Exceeding the product rating can cause loss of warranty, overheating and potential fire. Do not exceed product rating or tow vehicle lamp load rating, whichever is lower.

Check vehicle owner's manual or contact the vehicle manufacturer for more information.

INSTALLATION / SAFETY INSTRUCTIONS

Step 1

Remove each of the vehicle connector protective covers under the vehicle next to the rear bumper (A).

Step 2

Starting on the driver side, underneath the vehicle behind the removed protective overs, locate the vehicle taillight wiring harness connectors. The connectors will be similar to those on the custom wiring harness. Separate the connectors from the taillight housing taking care not to damage the locking tabs (B).

Step 3

Insert the custom wiring harness end with yellow wire between the separated connectors. Make sure the connectors are fully inserted with locking tabs in place.

Step 4

Repeat steps 2 and 3 for the passenger side, using the custom wiring harness end containing the green wire.



Locate a suitable grounding point near the connector such as an existing screw with nut in the vehicle frame or drill a 3/32" pilot hole for the provided screw. The area should be free of rust, dirt and paint. Secure the white ground wire using the ring terminal and provided screw.

S A WARNING: Check for miscellaneous items that may be hidden behind or under any surface before drilling to avoid damage and / or personal injury.

Step 6

Reinstall all items removed during install. Install the provided 4-flat dust cover to help prevent corrosion.



