

# 55373

LINCOLN LS

INSTALLATION QUESTIONS?  
CALL TECHNICAL SUPPORT AT  
1-800-798-0813

## WIRING LOCATION GUIDE GUÍA DE UBICACIÓN DEL CABLEADO IDE D'EMPLACEMENT DES FILS



### MUST READ FIRST!

All steps must be followed to ensure correct function of the T-Connector. To verify proper installation once installed, test by connecting a test light or properly wired trailer.

### ¡DEBE LEERSE PRIMERO!

Debe seguirse todos los pasos para asegurar el correcto funcionamiento del Conector-T. Para verificar la correcta instalación, pruebe conectando una luz de prueba o un remolque debidamente cableado.

### À LIRE D'ABORD!

Pour assurer le bon fonctionnement du T-Connector, il faut suivre toutes les étapes. Pour vérifier que l'installation a été bien effectuée, branchez un feu de test ou une remorque correctement filée.

5/24/2010



## English

1. Open the trunk and remove the floor coverings and rear scuff panel. [A] On the drivers and the passenger side's partially remove the felt trunk liner to expose the vehicles taillight wiring harness. [B]

2. On the drivers side separate the vehicles taillight wiring harness connectors being sure not to damage the locking tabs. Insert the T-connector end with the yellow wire in-between the separated connectors.

3. Route the T-connector end with the green wire out from behind the partially removed felt trim liner and behind the removed scuff panel and behind the felt trim liner on the passenger side. Repeat step 2 on the passenger side using the green wire.

4. Route the black power wire from the battery in the trunk to the converter as shown on the CME-PCL-INS sheet included. [C]

5. Locate a suitable grounding point near the connector such as an existing screw with nut in the vehicle's frame or drill a 3/32" hole and secure white wire using eyelet and screw provided.

6. Adhere the black converter box to the frame of the car using the double-sided tape provided. Secure any loose parts of the T-connector with the cable ties provided.

7. Route the 4-flat wire to the center of the vehicle and out the trunk when in use. When not in use roll up and store in an out of the way location in the trunk.

### WARNING!

Verify miscellaneous items that may be hidden behind or under any surface before drilling to avoid damage and/or personal injury.