

**INSTALLATION INSTRUCTIONS FOR
DYNOMAX VT MUFFLER KIT: 38311**

2007-99 Chevrolet Silverado / GMC Sierra 1500/2500
4.3L, 4.8L 5.3L Ext. Cab, Short Bed 143.5" W.B.
(<8600 GVWR) (2007 Classic only)



2701 N. Dettman Rd.
Jackson, MI 49201

DANGER WARNING: SHOULD THE PURCHASER DECIDE TO INSTALL ANY EXHAUST PRODUCT AT HOME, BE WARNED THAT PASSENGER CAR OR LIGHT DUTY TRUCK/VAN "BUMPER" JACKS ARE INTENDED FOR EMERGENCY USE ONLY. THE USE OF FRAME CONTACT JACK STANDS IN CONJUNCTION WITH A FLOOR JACK AS MAIN SUPPORT IS HIGHLY RECOMMENDED TO MINIMIZE ACCIDENTAL DROPPING OF A VEHICLE DURING THE INSTALLATION PROCESS.

NOTE: Read all instructions before beginning the installation.

1. Remove the OE muffler assembly. Lubricate the rubber isolators with WD-40 or similar product to aid in removing the rod brackets.
2. Install intermediate pipe **55512**. Insert the rod hanger into the rubber isolator hanger. Slightly tighten the inlet fasteners.
3. Install DynoMax VT muffler **17962**. The outlet end of the muffler is stamped on the shell.
4. Install tail pipe **55513**. Insert the required rod hangers into the rubber isolator hangers.

5. Beginning at the inlet end, position all components and tighten all clamps and fasteners.
6. Start the engine and check for leaks or rattles. Adjust as required. PLEASE SEE THE SYSTEM DIAGRAM ON THE BACK PAGE.

KIT CONTAINS:

- (1) 17962 VT MUFFLER
- (1) 55512 PIPE
- (1) 55513 PIPE
- (2) 3" CLAMPS
- (1) 711414 INSTRUCTION SHEET

38311 SYSTEM DIAGRAM

