



## **Truck and Jeep Accessories**

### **1999-2018 FORD F250, F350, SUPER DUTY BODY MOUNT HARDWARE KIT KF04057ST**



[www.Daystarweb.com](http://www.Daystarweb.com)

Tech Support Contact Info [Tech@DaystarWeb.com](mailto:Tech@DaystarWeb.com)

Phone: 623-907-0081

Fax: 623-907-0088

841 South 71<sup>st</sup> Avenue, Phoenix, AZ 85043

### **Introduction**

Daystar® is your number one source for Made in the USA quality vehicle accessories, backed by our exclusive *Go Everywhere*® Limited Lifetime Warranty (see terms at Daystarweb.com). To ensure your safety and proper installation of this product, take a moment to read all instructions and product safety information before trying to install your Daystar® product. If you have any technical questions after reading these instructions, we are here to help. Contact us at 800-595-7659.

### **Product Safety Information**

Throughout these instructions, important safety information is generally preceded by one of three signal words indicating the relative risk of injury. The signal words are as follows:



#### **WARNING**

A hazardous situation which, if not avoided, could result in death or serious injury. You can be seriously injured or killed if you don't follow instructions.



#### **CAUTION**

A hazardous situation which, if not avoided, could result in minor or moderate injury. You can be moderately injured and also may suffer property damage if you don't follow instructions.

#### **Notice**

Careful attention is required to this instruction or operation, but this does not generally relate to personal injury. Damage to your product or other property may result if you don't follow instructions.



<b>Bill of Materials</b>		
<b>Part #</b>	<b>Description</b>	<b>Quantity</b>
BP04057	Hardware Kit	1
-	Bolt: M12 x 1.75 x 130mm	2
-	Bolt: M12 x 1.75 x 110mm	6
-	Bolt: M12 x 1.75 x 150mm	6
-	Bolt: M12 x 1.75 x 200mm	2
-	Washer: M12	8

**Notice**

Provided Daystar hardware kit supplies your vehicle with replacement bolts for the various body mount locations. If the provided hardware does not fit your specific year, model, and trim level; reuse the factory hardware.

**2007-2016 F250/F350**

**2 Door Regular Cab/4 Door Crew Cab/4 Door Super Cab**

- (6) Bolt: M12 x 1.75 x 130 mm
- (2) Bolt: M12 x 1.75 x 110 mm
- (8) Washer: M12

**2017-2018 F250/F350**

**2 Door Regular Cab/4 Door Crew Cab/4 Door Super Cab**

- (6) Bolt: M12 x 1.75 x 150 mm
- (2) Bolt: M12 x 1.75 x 200 mm
- (8) Washer: M12

## Installation Instructions

This kit is meant to be used in conjunction with Daystar body mount kit KJ04050BK/KJ04050KV or other aftermarket body mount kits. Use the hardware provided in this kit when following the installation instructions of the body mount kit.

**Notice**

Verify that all parts are installed properly, all fasteners are torqued to factory specification, all lines, hoses, and wiring are not stretched or pinched. Retighten all bolts after 500 miles again to factory specifications.

