



Truck and Jeep Accessories



U.S. DESIGN PATENT NO. D521,923

INSTALLATION INSTRUCTIONS

**2015-16 Jeep Renegade
Bull Bar
KJ50005BK**

FOR TRAILHAWK MODELS ONLY!

Supplied Hardware:

Bull Bar - 1

Driver Mounting Bracket - 1

Passenger Mounting Bracket - 1

Bag Hardware Kit BU21877 consisting of:

3/8" x 1-1/4" Bolts, G5 - 4

3/8" Nylock Nuts - 4

3/8" SAE Flat Washers, G5 - 8

All hardware is supplied with each bracket set. Bullbar is not supplied with hardware. **This product retains the factory tow hooks.**

1. Remove the 2 bolts from each tow hook.
2. Slide the supplied light bar bracket between the tow hook & frame. **Note:** It is a fairly tight fit and the bracket will need to be wiggled into place.
3. Re-install bolts back into tow hooks, sandwiching the supplied light bar brackets. **Note:** Pull forward on tow hook when tightening bolts. Torque tow hook bolts to 65 foot lbs.
4. Hold lightbar parallel/straight with bumper lines and tighten 3/8" hardware. Install lights and wire according to light instructions.

www.DaystarWeb.com
Tech Support Contact Info
Tech@DaystarWeb.com

Phone: 623.907.0081
Fax 623.907.0088
841 S 71st Ave
Phoenix AZ 85043

Instruction Sheet P21853

©2016 Daystar Products International, Inc.

Revision 2

Revision: Date 07-06-16

Revised by: MS