

**RANCH HAND**

**1-800-366-9712**

**INSTALLATION INSTRUCTIONS**

**2006-`08 DODGE 1500 (EXCEPT 1500 MEGACAB)**

**PART # GGD06HBL1 (GRILL GUARD)**

1. Open hood. Remove the two inside bumper nuts on each side.
2. There is a driver and passenger side-mounting bracket. *See drawing.* Slide the bracket over the inside bumper bolts and reinstall nuts. You may have to raise or lower bracket for better fit later.
3. There is a driver and passenger side top bracket. *See drawing.* Use ½” bolt to install. Hand tighten.
4. Set grill guard on bumper and mount top brackets to rectangular holes in the uprights. Use ½” carriage bolts to install. Face bolts inward.
5. There is a driver and passenger side bottom bracket. *See drawing.* Mount bottom bracket to the bottom hole of the mounting bracket. Use ½” bolts to install. Mount the other end of the bottom bracket to the bottom hole of the grill guard. Hand tighten.
6. Center grill guard from left to right. Lower hood slowly to make sure you have clearance between the factory grill and the grill guard. Tighten all bolts and nuts.
7. ***MAKE SURE ALL NUTS AND BOLTS ARE TIGHT!***

---

**WARNING**

---

Special care should be exercised in the handling, storage and installation of Kaspar Ranch Hand equipment.

The actual weight of each piece of equipment will vary depending on style and model. The weight of the equipment is sufficient in volume to warrant special care, assistance and in some instances, the use of mechanical equipment during the transfer and installation of the equipment. Do not assume a position directly under the equipment during installation. Be sure the equipment has been connected and stabilized during installation to prevent falling or shifting of positions.

Periodically check tightness of bolts to make sure they are tight, and unlikely to fail.

Rev. 10/20/08