



EDELBROCK TENSIONER COVER
For Dual Quad LS/Small Block Chevy Supercharger
Part #15551 and #15553
INSTALLATION INSTRUCTIONS

PLEASE study these instructions carefully before beginning this installation. Most installations can be accomplished with common tools and procedures. However, you should be familiar with and comfortable working on your vehicle. If you do not feel comfortable performing this installation, it is recommended to have the installation completed by a qualified mechanic. If you have any questions, please call our **Technical Hotline at: 1-800-416-8628**, 7:00 am - 5:00 pm, Pacific Standard Time, Monday through Friday.

IMPORTANT NOTE: Proper installation is the responsibility of the installer.
Improper installation may result in poor performance and engine or vehicle damage.

Kit Content:

- 1 - Billet Tensioner Cover
- 1 - Set Screw
- 1 - Hex Flange Bolt, 3/8-16 x 3.5" (For Small Block Chevy Only)

Tools Required:

- Breaker Bar: 1/2"
- Hex/Allen Wrench: 3/32"
- Socket Wrench: 9/16" and 15mm
- Torque Wrench
- Blue Thread Locker

INSTALLATION INSTRUCTIONS

1. Using a 1/2" breaker bar, rotate the tensioner counterclockwise and remove the supercharger drive belt.
2. Use an appropriate socket wrench to remove the tensioner bolt. Place the billet tensioner cover onto the tensioner, aligning the tensioner slots.
3. Chevy LS applications will use the bolt removed from Step #2 to install the tensioner and tensioner cover. Chevy Small Block applications will use the supplied 3/8-16 x 3.5" tensioner bolt to install the tensioner and tensioner cover.
4. Verify that the slot on the tensioner cover is aligned with the slot on the tensioner. Install the tensioner bolt and torque to 37 ft-lbs.
5. Using a 1/2" breaker bar, rotate the tensioner counterclockwise and reinstall the supercharger drive belt.
6. Apply blue thread locker to the threads of the supplied set screw. Using a 3/32" Allen Wrench, install the set screw to secure the billet tensioner cover.

