2360 Boswell Road Chula Vista, CA 91914 Phone 619.216.1444 Fax 619.216.1474

E-Mail tech@explorerprocomp.com



PRO COMP SUSPENSION

Suspension Systems that Work!

Part #
PLF09119
2005-2008
Ford F250-F550
4WD
Coil Spacer Kit

This document contains very important information that includes warranty information and instructions for resolving problems you may encounter. Please keep it in the vehicle as a permanent record.

Part # Description Qty.
M03634-BK-01 COIL SPACER 2

Tools required				
Description:	Qty.			
Wrench set & Socket set	1			
Coil Spring Compressor	2			
Floor Jacks / Jack Stands	2/4			

RECOMMENDED PRO COMP SHOCKS						
	<u>Fron</u>	<u>t:</u>	Rear:			
W/Out Shock Relocation Bracket						
	<u>2005-2007</u>	<u>2008</u> <u>2005-</u>	<u> 2007</u>	<u>2008</u>		
ES9000	924553	923553	929508	929508		
MX-6	MX6087	MX6087	MX6018	MX6153		
With Shock Relocation Bracket (OE Length Shock)						
	<u>2005-2007</u>	<u>2008</u>	<u>2005-2007</u>	<u>2008</u>		
ES9000	922553	921553	929508	929508		
<u>MX-6</u>	MX6125	MX6119	MX6018	MX6153		

Optional Equipment Available from your Pro Comp Distributor!

52413B, 52513B, 52415B, 52515B, 52417B, 52421B: 2005-2007 SUSPENSION LIFT KITS 52800B, 52801B, 53860B, 52861B, 52880B, 52881B: 2008 SUSPENSION LIFT KITS 52440B, 52450B: 2005-2007 FRONT DUAL SHOCK KITS, (Use With Suspension Lift Kit) 52432B, 52434B: 2005-2007 DUAL FRONT COIL OVER LIFT KITS, 52438B: 2005-2007 DUAL FRONT COIL OVER UPGRADE KITS, 52470B,52460B: 2008 FRONT DUAL SHOCK KITS, (Use With Suspension Lift Kit) 52838B,52848B: 2008 DUAL FRONT COIL OVER LIFT KITS, 52858B,52868B: 2008 DUAL FRONT COIL OVER UPGRADE KITS, 22415 (x2): 2005-2007 LEAF SPRINGS, (Use With Suspension Lift Kit) 22518 (x2): 2008LEAF SPRINGS, (Use With Suspension Lift Kit) 95-550SD (x2): 5 1/2" LIFT BLOCK, (Use With Suspension Lift Kit) 95-400SD (x2): 4" LIFT BLOCK, (Use With Suspension Lift Kit)

LIGHTS,
599: ALIGNMENT CAM KIT,
72400: TRACTION BARS,
72099: TRACTION BAR MOUNTING KIT
219567: DUAL STEERING STABILIZER
99-400: 4 DEGREE REAR AXLE SHIM KIT

Also, check out our outstanding selection of $\operatorname{\mathtt{Pro}}$ $\operatorname{\mathtt{Comp}}$ tires to compliment your new installation!

Introduction:


- This installation requires a professional mechanic!
- We recommend that you have access to a factory service manual to assist in the disassembly and reassembly of your vehicle. It contains a wealth of detailed information.
- Prior to installation, carefully inspect the vehicle's steering and driveline systems paying close attention to the tie rod ends, ball joints, wheel bearing preload, pitman and idler arms. Additionally, check steering-to-frame and suspension-to-frame attaching points for stress cracks. The overall vehicle must be in excellent working condition. Repair or replace all worn or damaged parts!
- Read the instructions carefully and study the illustrations before attempting installation! You may save yourself a lot of extra work.
- Check the parts and hardware against the parts list to assure that your kit is complete. Separating parts according to the areas where they will be used and placing the hardware with the brackets before you begin will save installation time.
- Check the special equipment list and ensure the availability of these tools.
- Secure and properly block vehicle prior to beginning installation.
- <u>ALWAYS</u> wear safety glasses when using power tools or working under the vehicle!
- Use caution when cutting is required under the vehicle. The factory undercoating is flammable. Take appropriate precautions. **Have a fire extinguisher close at hand.**
- Foot pound torque readings are listed on the Torque Specifications chart at the end of the instructions. These are to be used unless specifically directed otherwise. Apply thread lock retaining compound where specified.
- Please note that while every effort is made to ensure that the installation of your Pro Comp lift kit is a positive experience, variations in construction and assembly in the vehicle manufacturing process will virtually ensure that some parts may seem difficult to install. Additionally, the current trend in manufacturing of vehicles results in a frame that is highly flexible and may shift slightly on disassembly prior to installation. The use of pry bars and tapered punches for alignment is considered normal and usually does not indicate a faulty product. However, if you are uncertain about some aspect of the installation process, please feel free to call our tech support department at the number listed on the cover page. We do not recommend that you modify the Pro Comp parts in any way as this will void any warranty expressed or implied by the Pro Comp Suspension company.


Please Note:


- ⇒ Front suspension and head light realignment is <u>necessary</u>!
- ⇒ Speedometer and ABS recalibration will be necessary if larger tires (10% more than stock diameter) are installed.
- ⇒ IT IS ADVISABLE THAT YOU HAVE HELP AVAILABLE WHEN INSTALLING THIS KIT. SOME COMPONENTS ARE HEAVY AND AWKWARD. AN ADDITIONAL SET OF HANDS IS GOOD INSURANCE AGAINST INJURY!

Installation:

- Layout all parts and check quantities against the Bill of Materials. Completely read instructions before beginning installation.
- 2. Make sure you are working on a level, stable concrete surface or using a lift to perform this work.
- 3. Jack the front of the vehicle in accordance to manufacturer recommendation and support vehicle with jack stands, use the floor jacks to support the axle so it can be lifted and lowered relative to the vehicle.
- 4. Remove front wheels.
- 5. Raise the axle using the floor jacks enough to relieve tension in the shocks.
- 6. Disconnect endlinks to sway bar, brake line bracket and OE shocks (both sides). *Fig.1*
- 7. Lower the front axle as far as possible. Remove only one spring (mark or note spring orientation before removal). Remove OE spring isolator.
- 8. Compress spring down, install new isolator (M03634) and reinstall spring.
- 9. Repeat steps 7 and 8 for other side.
- 10. Lift axle back up and install new shocks, brake line bracket (Fig.3) and reconnect sway bar endlinks.
- 11. Put wheels back on (torque to manufacture's spec.) and lower vehicle to ground.












Use this only as a guide for hardware without a called out torque specification in the instruction manual.



Notice to Owner operator, Dealer and Installer:

Vehicles that have been enhanced for off-road performance often have unique handling characteristics due to the higher center of gravity and larger tires. This vehicle may handle, react and stop differently than many passenger cars or unmodified vehicles, both on and off-road. You must drive your vehicle safely! Extreme care should always be taken to prevent vehicle rollover or loss of control, which can result in serious injury or even death. Always avoid sudden sharp turns or abrupt maneuvers and allow more time and distance for braking! Pro Comp reminds you to fasten your seat belts at all times and reduce speed! We will gladly answer any questions concerning the design, function, maintenance and correct use of our products.

Please make sure your Dealer/Installer explains and delivers all warning notices, warranty forms and instruction sheets included with Pro Comp product.

Application listings in this catalog have been carefully fit checked for each model and year denoted. However, Pro Comp reserves the right to update as necessary, without notice, and will not be held responsible for misprints, changes or variations made by vehicle manufacturers. Please call when in question regarding new model year, vehicles not listed by specific body or chassis styles or vehicles not originally distributed in the USA.

Please note that certain mechanical aspects of any suspension lift product may accelerate ordinary wear of original equipment components. Further, installation of certain Pro Comp products may void the vehicle's factory warranty as it pertains to certain covered parts; it is the consumer's responsibility to check with their local dealer for warranty coverage before installation of the lift.

Warranty and Return policy:

Pro Comp warranties its full line of products to be free from defects in workmanship and materials. Pro Comp's obligation under this warranty is limited to repair or replacement, at Pro Comp's option, of the defective product. Any and all costs of removal, installation, freight or incidental or consequential damages are expressly excluded from this warranty. Pro Comp is not responsible for damages and / or warranty of other vehicle parts related or non-related to the installation of Pro Comp product. A consumer who makes the decision to modify his vehicle with aftermarket components of any kind will assume all risk and responsibility for potential damages incurred as a result of their chosen modifications. Warranty coverage does not include consumer opinions regarding ride comfort, fitment and design. Warranty claims can be made directly with Pro Comp or at any factory authorized Pro Comp dealer.

IMPORTANT! To validate the warranty on this purchase please be sure to mail in the warranty card.

Claims not covered under warranty-

- Parts subject to normal wear, this includes bushings, bump stops, ball joints, tie rod ends and heim joints
 - Discontinued products at Pro Comp's discretion
- Bent or dented product
- Finish after 90 days
- Leaf or coil springs used without proper bump stops
- Light bulbs
- Products with evident damage caused by abrasion or contact with other items
- Damage caused as a result of not following recommendations or requirements called out in the installation manuals
- Products used in applications other than listed in Pro Comp's catalog
- Components or accessories used in conjunction with other manufacturer's systems
- Tire & Wheel Warranty as per Pro Competition Tire Company policy
- Warranty claims without "Proof of Purchase"
- Pro Comp Pro Runner coil over shocks are considered a serviceable shock with a one-year warranty against leakage only. Rebuild service and replacement parts will be available and sold separately by Pro Comp. Contact Pro Comp for specific service charges.
- Pro Comp accepts no responsibility for any altered product, improper installation, lack of or improper maintenance, or improper use of our products.

E-Mail: tech@explorerprocomp.com Website: www.explorerprocomp.com

Fax: (619) 216-1474 Ph: (619) 216-1444 PLACE
WARRANTY REGISTRATION
NUMBER
HERE: