

SAFETY

Your safety and the safety of others is very important.

- In order to help you make informed decisions about safety, we have provided installation instructions and other information.
- These instructions alert you to potential hazards that could hurt you or others.
- Please do a job safety analysis (JSA) before each task to identify potential hazards for your situation and remove/protect against them.
- You must use your own good judgment, and take your time.

Read and understand all safety precautions and instructions before installing this product.

THIS PRODUCT IS FOR OFFROAD USE ONLY. ALL LIABILITY FOR INSTALLATION AND USE RESTS WITH THE OWNER.

CARELESS INSTALLATION AND OPERATION CAN RESULT IN SERIOUS INJURY OR EQUIPMENT DAMAGE.

Injury hazard

Failure to observe these instructions could lead to severe injury or death.

- Always remove jewelry and wear eye protection.
- Always use appropriate and adequate care in lifting components into place.
- Always insure components will remain secure during installation and operation.
- □ Always wear safety glasses when installing this kit
- Always use extreme caution when cutting and trimming during fitting.
- Always tighten all nuts and bolts securely per installation instructions.
- □ Always perform regular inspections and maintenance on mounts and related hardware.



Copyright 2009 Fab Fours, Inc.



Overview

Congratulations on your new purchase of the front fender flare.

Your fenders and flares were designed in 3-D from digitized data, CNC laser cut, fabricated, and powder coated... all in the U.S.A. Enjoy the fit and finish of a quality front fender flares from Fab Fours, Inc.





I. Tools Required

- Allen wrenches
- Anti-seize (recommended)

II. Factory Fender Removal (perform steps for each side)

1. Remove the marker light from the rubber grommet and then remove the rubber grommet from the fender base skin.

2. Unbolt the front 7 3/8-16 button head bolts from the fender base and skin.



3. With the help of another, hold the fender flare near the mounting position and feed the marker light and grommet through the clearance hole under the flare.

4. With the help of another, position the fender flare on the fender base skin being careful not to damage the fender base skin powder coat. Carefully thread a couple bolts through the flare and skin and into the base.







5. Loosely install the remaining bolts in the fender flare. Note: Anti-seize is always recommended when using stainless steel hardware. Using anti-seize will reduce chances of having to cut out a bolt.

6. Position the fender where you want it in the slots of the flare and fully tighten down all hardware.

7. Fish the marker light and grommet through the new light mounting hole and reinstall the light.

8. Using zip ties, secure the marker light wires to the wire path and zip tie holes.

Note: 3/8" wire loom is recommended for a clean appearance.





9. Install top cover plates using includes 3/8" hardware to the top of the fender flairs



10. Your fender flares are now properly installed!





III.Maintenance/Care

- Periodically check and tighten all nuts.
- □ Stripped, fractured, or bent bolts or nuts need to be replaced.

IV. Contact Information

Fab Fours Inc. 2213 Industrial Park Road Lancaster, SC 29720

Phone	(866)-385-1905
Fax	(970)-385-1914
Email	Support@fabfours.com



More than expected... Better than expected.

